


Z3V0E1500A


Ref #	Part #	Description
1	17211-Z0Z-000	ELEMENT, AIR CLEANER
2	17220-Z0Z-010	HOUSING, AIR CLEANER
3	17231-Z0Z-010	COVER, AIR CLEANER
4	90009-Z3F-901	BOLT, SOCKET (5X25)
5	90018-Z0H-003	BOLT, SOCKET (5X16)
5	90018-Z3E-901	BOLT, SOCKET (5X16)
6	94050-05000	NUT, FLANGE (5MM)
7	91501-Z0Z-000	COLLAR, AIR CLEANER HOUSING
8	91503-ZM3-000	COLLAR, AIR CLEANER
9	91506-ZM3-000	COLLAR A, HEAD COVER



Z6K0-E1000




Ref #	Part #	Description
1	12209-Z3E-003	SEAL, VALVE STEM
2	14126-Z0Z-003	ROLLER (4X31.8)
3	14320-Z0Z-000	PULLEY, CAMSHAFT
4	14400-Z3F-801	BELT, TIMING (76ZU5 G-310)
5	14711-Z3F-000	VALVE, IN. (FI)
6	14721-Z3F-000	VALVE, EX. (FE)
7	14751-Z0Z-000	SPRING, VALVE
8	14771-Z3F-000	RETAINER, VALVE SPRING



Z6K0E1400B


Ref #	Part #	Description
1	16010-ZM3-004	GASKET, METERING DIAPHRAGM
2	16011-Z0H-013	GASKET, PUMP
3	16013-Z0H-003	DIAPHRAGM ASSY., METERING
4	16014-ZM3-004	DIAPHRAGM, PUMP
5	16015-Z0H-013	BODY ASSY., PUMP (CARBURETOR NO.)
5	16015-Z6J-023	BODY ASSY., PUMP (CARBURETOR NO.)
6	16017-ZM3-004	BODY ASSY., AIR PURGE
7	16018-ZM3-802	SCREEN, INLET
8	16019-ZM3-004	VALVE, INLET NEEDLE
9	16020-ZM3-004	SPRING, METERING LEVER
10	16021-ZM3-004	SCREW, METERING LEVER PIN
11	16022-ZM3-014	PIN, METERING LEVER
12	16023-ZM3-004	LEVER, METERING
13	16024-Z0H-003	RING, RETAINING
14	16025-ZM3-004	O-RING
15	16026-ZM3-004	COVER, PRIMER PUMP
16	16027-ZM3-004	SWIVEL
17	16028-ZM3-004	SCREW, THROTTLE COLLAR
18	16029-ZM3-004	SCREW, PUMP COVER
19	16030-ZM3-004	SPRING, PUMP
20	16031-ZM3-004	WASHER
21	16032-ZM3-004	PUMP, PRIMER (NOT AVAILABLE)
21	16032-ZM3-014	PUMP, PRIMER
22	16035-ZM3-802	FILTER, FUEL INLET
23	16100-Z0Z-815*	CARBURETOR ASSY. (WYB 14D/E) (NOT AVAILABLE)

23	16100-Z0Z-816	CARBURETOR ASSY. (WYB 14D/E)
23	16100-Z6K-803	CARBURETOR ASSY. (WYB 36A/B)
23	16100-Z6K-804	CARBURETOR ASSY. (WYB 36A/B)
24	16221-Z0Z-000*	GASKET, CARBURETOR
25	19631-Z0Z-010	SHROUD
25	19631-Z0Z-020	SHROUD
26	90014-Z0H-003	BOLT (5X53)
27	90018-Z0H-003	BOLT, SOCKET (5X16)
27	90018-Z3E-901	BOLT, SOCKET (5X16)
28	91301-ZM3-000	O-RING (14.8X2.4)
29	91308-Z3E-000	O-RING (12.3X2.4)
30	99101-Z0Z-0360	JET (#36) (CARBURETOR NO.)
30	99101-Z0Z-0370	JET (#37) (CARBURETOR NO.)
30	99101-Z0Z-0380	JET (#38) (CARBURETOR NO.)
30	99101-ZM5-0350	JET (#35) (CARBURETOR NO.)




Ref #	Part #	Description
1	10100-Z3F-405	CRANKCASE SET
2	12310-Z0Z-000	COVER, CYLINDER HEAD
2	12310-Z0Z-010	COVER, CYLINDER HEAD
3	12312-Z0Z-300	SEAL, HEAD COVER
4	12314-Z0H-300	GROMMET, HEAD COVER
5	12367-Z0H-000	FILTER, BREATHER
6	14431-Z0H-003	ARM, IN. VALVE ROCKER
7	14441-Z0H-003	ARM, EX. VALVE ROCKER
8	14730-Z0Z-000	LIFTER, IN. VALVE
9	14740-Z0Z-000	LIFTER, EX. VALVE
10	15422-Z0Z-000	TUBE, OIL
11	15510-Z3E-000	PLATE ASSY., OIL OUTLET VALVE
12	15600-Z3F-000	CAP ASSY., OIL FILLER
13	15625-Z0T-800	GASKET, OIL FILLER CAP
14	15721-Z0Z-000	TUBE, BREATHER
15	31914-Z0H-003	SPARK PLUG (CMR4H) (NGK)
15	31915-Z0H-003	SPARK PLUG (CMR5H) (NGK)
15	31916-Z0H-003	SPARK PLUG (CMR6H) (NGK)
16	90009-Z0H-003	BOLT, SOCKET (5X20)
16	90009-Z3E-901	BOLT, SOCKET (5X20)
17	90010-Z0Z-003	BOLT, SOCKET (5X32)
18	90013-Z0H-004	SCREW, PAN (4X8)
18	90013-Z3E-003	SCREW, PAN (4X8)
19	90013-Z0Z-003	SCREW, PAN (4X8) (NOT AVAILABLE)
19	90013-Z3F-003	SCREW, PAN (4X8)

20	90017-Z0H-000	SCREW, TAPPET ADJUSTING
21	90019-Z0H-003	BOLT, SOCKET (5X12)
22	90206-ZM3-000	NUT, TAPPET ADJUSTING
23	94305-40102	PIN, SPRING (4X10)
24	95002-41200-08	CLAMP, TUBE (D12)
25	95002-41300-04	CLAMP, TUBE (D13)



Z6K0-E1200


Ref #	Part #	Description
1	19611-Z3V-000	COVER, FAN
2	22000-Z3V-003	CLUTCH ASSY.
3	22253-Z3F-000	BOLT, CLUTCH (8MM)
4	22254-Z3F-000	WASHER, CLUTCH (8X17)
5	22255-Z3F-000	WASHER, WAVE (10MM)
6	90009-Z0H-003	BOLT, SOCKET (5X20)
6	90009-Z3E-901	BOLT, SOCKET (5X20)



FR. →

Z6K0-E1900


Ref #	Part #	Description
1	30500-Z3F-013	COIL ASSY., IGNITION
2	30522-Z3F-000	CLIP, IGNITION WIRE
3	31110-Z3F-003	FLYWHEEL
4	32195-Z0Z-000	WIRE, STOP SWITCH
5	90012-Z0H-005	BOLT, SOCKET (4X14)
5	90012-Z3E-003	BOLT, SOCKET (4X14)
6	94050-08000	NUT, FLANGE (8MM)



Z6K0E1700J


Ref #	Part #	Description
1	17504-ZM3-003	GROMMET, FUEL TUBE
1	17504-ZM3-003	GROMMET, FUEL TUBE
1	17504-ZM3-003	GROMMET, FUEL TUBE
2	17511-Z0Z-305	TANK, FUEL (COO)
2	17511-Z6K-820	TANK, FUEL
2	17511-Z6K-821	TANK, FUEL
5	17533-Z0H-000	RUBBER, TANK MOUNTING
7	17620-ZM3-818	CAP ASSY., FUEL TANK
8	17672-Z0H-003	FILTER, FUEL
11	17702-Z0Z-000	TUBE, FUEL RETURN
16	91401-Z3E-000	CLIP, TUBE (B1 5)
16	91401-Z3E-000	CLIP, TUBE (B1 5)
16	91401-ZM3-003	CLIP, TUBE
16	91401-ZM3-003	CLIP, TUBE
22	16865-Z6K-000	PROTECTOR, TUBE
23	17519-Z6J-003	JOINT, FUEL TANK
23	17519-Z6J-003	JOINT, FUEL TANK
24	17701-Z6J-305	TUBE, FUEL
24	17701-Z6K-315	TUBE, FUEL (FKM)
25	17702-Z0H-003	TUBE, FUEL RETURN
25	17702-Z0H-003	TUBE, FUEL RETURN
26	17703-Z6K-801	TUBE A, FUEL
26	17703-Z6K-801	TUBE A, FUEL
26	17703-Z6K-801	TUBE A, FUEL
27	90601-Z6J-003	CLAMP, TUBE

27	90601-Z6J-003	CLAMP, TUBE
27	90601-Z6J-003	CLAMP, TUBE
29	17700-Z0Z-305	GROMMET ASSY., FUEL TANK
29	17700-Z0Z-307	GROMMET ASSY., FUEL TANK
30	17504-ZM3-003	GROMMET, FUEL TUBE
30	17504-ZM3-003	GROMMET, FUEL TUBE
30	17504-ZM3-003	GROMMET, FUEL TUBE
31	17519-ZM5-003	FITTING
32	17701-Z3F-315	TUBE, FUEL FEED
33	17703-Z6K-801	TUBE A, FUEL
33	17703-Z6K-801	TUBE A, FUEL
33	17703-Z6K-801	TUBE A, FUEL
34	91401-ZM3-003	CLIP, TUBE
34	91401-ZM3-003	CLIP, TUBE
35	16865-Z6J-010	PROTECTOR, TUBE
36	17504-ZM3-003	GROMMET, FUEL TUBE
36	17504-ZM3-003	GROMMET, FUEL TUBE
36	17504-ZM3-003	GROMMET, FUEL TUBE
37	17519-Z6J-003	JOINT, FUEL TANK
37	17519-Z6J-003	JOINT, FUEL TANK
38	17701-Z6K-883	TUBE, FUEL (FKM)
38	17701-Z6K-884	TUBE, FUEL (FKM)
39	17702-Z0H-003	TUBE, FUEL RETURN
39	17702-Z0H-003	TUBE, FUEL RETURN
40	17703-Z6K-801	TUBE A, FUEL
40	17703-Z6K-801	TUBE A, FUEL
40	17703-Z6K-801	TUBE A, FUEL
41	90601-Z6J-801	CLAMP, TUBE (D5.5)
41	90601-Z6J-801	CLAMP, TUBE (D5.5)
42	90601-Z6J-801	CLAMP, TUBE (D5.5)
42	90601-Z6J-801	CLAMP, TUBE (D5.5)
43	91401-Z3E-000	CLIP, TUBE (B1 5)
43	91401-Z3E-000	CLIP, TUBE (B1 5)




Z6K0E2800D

Ref #	Part #	Description
1	87114-Z3E-000	LABEL, WARNING (NOT CERTIFIED FOR SALE)
2	87521-Z3F-000	MARK, EMBLEM
2	87521-Z3F-010	MARK, EMBLEM
3	87531-Z0Z-000	MARK, HONDA
4	87601-Z4A-000	MARK, TYPE (S3)
5	87660-Z0Z-000	MARK (4-STROKE)
5	87660-Z3F-900	MARK (4-STROKE)
7	87516-Z6J-010	MARK, OPERATOR CAUTION (ENGLISH)
9	87521-Z3F-901	MARK, EMBLEM




Z6K0E1600A

Ref #	Part #	Description
1	18310-Z0Z-802	MUFFLER (ARRESTER)
2	18350-Z0Z-800	ARRESTER, SPARK
2	18350-Z0Z-801	ARRESTER, SPARK
3	18354-Z0Z-800	FILTER, EX.
4	18515-Z0Z-300	GUIDE, AIR
5	18518-Z0Z-020	GUIDE, AIR (LOWER)
6	90001-Z0Z-013	BOLT, STUD (5X56.5)
7	90018-Z0H-003	BOLT, SOCKET (5X16)
7	90018-Z3E-901	BOLT, SOCKET (5X16)
8	90055-ZE1-000	SCREW, TAPPING (4X6)
9	90136-SM4-901	NUT, SELF-LOCK (5MM)
10	91506-ZM3-000	COLLAR A, HEAD COVER




Z6K0E4001B

Ref #	Part #	Description
1	87516-Z6J-801	MARK, OPERATOR CAUTION (FRENCH)
2	87522-ZK6-800	LABEL, CAUTION (CHINA)
3	87519-Z6J-000	MARK, OPERATOR CAUTION (PICTOGRAPH)
3	87519-Z6J-010	MARK, OPERATOR CAUTION (PICTOGRAPH)




Ref #	Part #	Description
1	28400-Z0Z-315	STARTER ASSY., RECOIL (COO)(FOR U.S.A.)
1	28400-Z3F-M01	STARTER ASSY., RECOIL
2	28414-Z0Z-000	CASE, RECOIL STARTER
2	28414-Z3F-M01	CASE, RECOIL STARTER
4	28421-ZM3-003	REEL, RECOIL STARTER
5	28433-ZM3-003	GUIDE, ROPE
6	28442-Z0H-003	SPRING, RECOIL STARTER
7	28451-Z0H-003	PULLEY, RECOIL STARTER
8	28459-Z0H-003	SWINGARM
9	28461-Z3F-M01	NOB, RECOIL STARTER
9	28461-ZM3-003	NOB, RECOIL STARTER
10	28462-ZM3-003	ROPE, RECOIL STARTER
11	90012-ZM3-003	SCREW, SETTING
12	90018-Z0H-003	BOLT, SOCKET (5X16)
12	90018-Z3E-901	BOLT, SOCKET (5X16)
13	91504-ZM3-003	COLLAR
14	91506-ZM3-000	COLLAR A, HEAD COVER



Z6K0-E2900

Ref #	Part #	Description
1	89216-VJ3-J10	WRENCH, PLUG (16X19)
2	89221-KW3-000	WRENCH, HEX. (4MM)
3	90011-Z0H-811	BOLT, SOCKET (5X9)
4	99005-01000	BAR A, HANDLE



Ref #	Part #	Description
1	19720-Z0Z-020ZA	COVER, TOP *R280* (POWER RED)
2	90015-Z0H-003	BOLT, TOP COVER
3	90015-Z3E-900	BOLT, TOP COVER