



Ref #	Part #	Description
1	17211-ZE1-000*	ELEMENT, AIR CLEANER (SEMI-DRY)
2	17231-ZE1-000	COVER, AIR CLEANER (SEMI-DRY)
3	17238-ZE7-010	COLLAR, AIR CLEANER
4	17239-ZE1-000	COLLAR B, AIR CLEANER
5	17250-Z0T-810	GRID, AIR CLEANER
6	17410-ZE1-030	ELBOW, AIR CLEANER
7	17421-ZE1-000	CAP, CLEANER
8	90325-044-000	NUT, TOOL BOX SETTING
9	94050-06000	NUT, FLANGE (6MM)
10	95701-06020-00	BOLT, FLANGE (6X20)



FR. →

ZED0E0900


Ref #	Part #	Description
1	12209-Z4M-801	SEAL, VALVE STEM
1	12209-ZH8-003	SEAL, VALVE STEM
2	14100-Z1T-930	CAMSHAFT ASSY.
2	14100-Z4M-000	CAMSHAFT ASSY.
3	14410-Z4M-000	ROD, PUSH
4	14431-Z1T-000	ARM, VALVE ROCKER
4	14431-ZE1-000	ARM, VALVE ROCKER
5	14441-ZE1-010	LIFTER, VALVE
6	14451-Z4M-000	PIVOT, ROCKER ARM
6	14451-Z7E-000	PIVOT, ROCKER ARM
7	14568-ZE1-000	SPRING, WEIGHT RETURN
8	14711-Z1T-930	VALVE, IN.
9	14721-Z4M-000	VALVE, EX.
10	14751-ZF1-000	SPRING, VALVE
11	14771-Z0T-900	RETAINER, VALVE SPRING
11	14771-Z1T-000	RETAINER, VALVE SPRING
12	14791-Z4M-000	PLATE, PUSH ROD GUIDE
13	90012-ZE0-010	BOLT, PIVOT (8MM)
14	90206-ZE1-000	NUT, PIVOT ADJUSTING



ZED0E1400


Ref #	Part #	Description
1	16010-ZE1-812	GASKET SET
2	16011-ZE0-005	VALVE SET, FLOAT (SEAT NOT INCLUDED)
3	16013-Z0S-B01	FLOAT SET
4	16015-Z4M-911	CHAMBER SET, FLOAT
5	16016-ZDF-V01	SCREW SET
6	16024-Z5T-901	SCREW SET, DRAIN
7	16028-Z5T-901	SCREW SET
8	16044-ZE0-005	CHOKE SET
9	16100-Z4M-WC1*	CARBURETOR ASSY. (BE99M A)
10	16124-ZE0-005	SCREW, THROTTLE STOP
11	16141-Z0S-003	WASHER, PLAIN (6.2X10.7 DRAIN)
12	16166-Z4M-WC1	NOZZLE, MAIN
13	16173-001-004	O-RING
14	16211-Z4M-900*	INSULATOR, CARBURETOR
15	16212-Z1T-701	GASKET, INSULATOR (NINGBO SIL GASKET)
15	16212-ZH8-800*	GASKET, INSULATOR
16	16220-ZE1-020	SPACER, CARBURETOR
17	16221-Z1T-701	GASKET, CARBURETOR (NINGBO SIL GASKET)
17	16221-ZH8-801*	GASKET, CARBURETOR
18	16610-Z1T-000	LEVER, CHOKE (STD)
18	16610-ZE1-000	LEVER, CHOKE (STD)
19	16953-ZE1-812	LEVER, PETCOCK
20	16954-ZE1-812	PLATE, LEVER SETTING
21	16956-ZE1-811	SPRING, PETCOCK LEVER
22	16957-ZE1-812	GASKET, PETCOCK

23	16959-Z5T-901	FILTER, CUP
24	16967-ZE0-811	CUP, FUEL STRAINER
25	93500-03006-0H	SCREW, PAN (3X6)
26	94305-20122	PIN, SPRING (2X12)
27	99101-ZK7-0600	JET, MAIN (#60)
27	99101-ZK7-0620	JET, MAIN (#62)
27	99101-ZK7-0650	JET, MAIN (#65)
28	99204-ZE2-0400	JET SET, PILOT (#40)




ZED0E2200A

Ref #	Part #	Description
1	16500-Z4M-810	CONTROL ASSY. (REMOTE/INTERNAL)
6	16551-Z4M-000	ARM, GOVERNOR
7	16555-Z0T-N70	ROD, GOVERNOR
7	16555-Z4M-000	ROD, GOVERNOR
8	16561-Z4M-010	SPRING, GOVERNOR
9	16562-ZE1-020	SPRING, THROTTLE RETURN
10	16571-Z4M-000	LEVER, CONTROL
11	16574-ZE1-000	SPRING, LEVER
12	16575-ZH8-000	WASHER, CONTROL LEVER
13	16576-891-000	HOLDER, CABLE
14	16578-ZE1-000	SPACER, CONTROL LEVER
15	16580-Z4M-810	BASE, CONTROL
16	16584-883-300	SPRING, CONTROL ADJUSTING
17	16592-ZE1-810	SPRING, CABLE RETURN
18	16594-883-010	HOLDER, WIRE
20	90013-883-000	BOLT, FLANGE (6X12) (CT200)
21	90015-Z5T-000	BOLT, GOVERNOR ARM
23	90202-Z1T-000	NUT, SELF-LOCK (6MM)
24	90605-Z1T-000	CIRCLIP (5MM)
25	93500-04006-0H	SCREW, PAN (4X6)
26	93500-05016-0A	SCREW, PAN (5X16)
27	93500-05025-0H	SCREW, PAN (5X25)
29	94050-06000	NUT, FLANGE (6MM)




ZED0E0600

Ref #	Part #	Description
1	11300-Z4M-630	COVER ASSY., CRANKCASE
2	11381-Z1T-701	GASKET, CASE COVER (NINGBO SIL GASKET)
2	11381-ZH8-801	GASKET, CASE COVER (NON-ASBESTOS)
3	15600-Z0T-810	CAP ASSY., OIL FILLER (GAUGE)(GRAY)
3	15600-ZE1-003	CAP ASSY., OIL FILLER (GRAY)
4	15600-Z0T-820	CAP ASSY., OIL FILLER (BLACK)
4	15600-ZG4-003	CAP ASSY., OIL FILLER
5	15625-Z0T-800	GASKET, OIL FILLER CAP
5	15625-Z1T-000	GASKET, OIL FILLER CAP
6	91201-Z0T-801	OIL SEAL (25X41X6) (NOK)
6	91202-YA0-P01	OIL SEAL (25X41X6) (ARAI)
6	91202-Z1T-003	OIL SEAL (25X41X6) (ARAI)
7	94301-08140	PIN, DOWEL (8X14)
8	95701-08032-00	BOLT, FLANGE (8X32)
9	96100-62050-00	BEARING, RADIAL BALL (6205)




ZED0E0700

Ref #	Part #	Description
2	13310-ZED-860	CRANKSHAFT
6	91001-Z1T-003	BEARING, RADIAL BALL (6205) (NSK)




FR. 
ZED0E0300A

Ref #	Part #	Description
1	12000-Z4M-426	CYLINDER ASSY. (OIL ALERT)
2	16510-Z4M-000	GOVERNOR ASSY.
3	16531-Z4M-000	SLIDER, GOVERNOR
4	16541-Z4M-000	SHAFT, GOVERNOR ARM
5	35480-Z0T-003	SWITCH ASSY., OIL LEVEL
6	90131-ZE1-000	BOLT, DRAIN PLUG
8	90601-ZE1-000	WASHER, DRAIN PLUG (10.2MM)
9	90602-ZE1-000	CLIP, GOVERNOR HOLDER
10	91201-Z0T-801	OIL SEAL (25X41X6) (NOK)
10	91202-YA0-P01	OIL SEAL (25X41X6) (ARAI)
10	91202-Z1T-003	OIL SEAL (25X41X6) (ARAI)
11	91353-Z7E-003	O-RING (14MM)
12	94050-10000	NUT, FLANGE (10MM)
13	94101-06800	WASHER, PLAIN (6MM)
14	94251-08000	PIN, LOCK (8MM)
15	95701-06012-00	BOLT, FLANGE (6X12)
16	16511-Z4M-000	WEIGHT, GOVERNOR
17	16512-Z4M-000	HOLDER, GOVERNOR WEIGHT
18	16513-ZE1-000	PIN, GOVERNOR WEIGHT




ZED0E0200A

Ref #	Part #	Description
3	12210-Z1T-407	CYLINDER HEAD
5	12251-ZL0-003	GASKET, CYLINDER HEAD (NIPPON LEAKLESS)
7	12310-ZDA-000	COVER, HEAD
8	12312-Z1T-701	GASKET, HEAD COVER (NINGBO SIL GASKET)
8	12391-ZE1-000	GASKET, HEAD COVER
10	15721-ZH8-000	TUBE, BREATHER
11	90013-883-000	BOLT, FLANGE (6X12) (CT200)
12	90043-ZDK-000	BOLT, STUD (6X112)
13	90047-ZDK-000	BOLT, STUD (8X32)
14	94301-10160	PIN, DOWEL (10X16)
16	95701-08060-00	BOLT, FLANGE (8X60)
17	98079-55846*	SPARK PLUG (BPR5ES) (NGK)
17	98079-55855	SPARK PLUG (W16EPR-U) (DENSO)
17	98079-56846	SPARK PLUG (BPR6ES) (NGK)
17	98079-56855	SPARK PLUG (W20EPR-U) (DENSO)



ZED0E1200


Ref #	Part #	Description
3	12210-Z1T-407	CYLINDER HEAD
5	12251-ZL0-003	GASKET, CYLINDER HEAD (NIPPON LEAKLESS)
7	12310-ZDA-000	COVER, HEAD
8	12312-Z1T-701	GASKET, HEAD COVER (NINGBO SIL GASKET)
8	12391-ZE1-000	GASKET, HEAD COVER
10	15721-ZH8-000	TUBE, BREATHER
11	90013-883-000	BOLT, FLANGE (6X12) (CT200)
12	90043-ZDK-000	BOLT, STUD (6X112)
13	90047-ZDK-000	BOLT, STUD (8X32)
14	94301-10160	PIN, DOWEL (10X16)
16	95701-08060-00	BOLT, FLANGE (8X60)
17	98079-55846	SPARK PLUG (BPR5ES) (NGK)
17	98079-55855	SPARK PLUG (W16EPR-U) (DENSO)
17	98079-56846	SPARK PLUG (BPR6ES) (NGK)
17	98079-56855	SPARK PLUG (W20EPR-U) (DENSO)



FR. →


ZED0E1900

Ref #	Part #	Description
1	13331-Z8B-900	KEY, SPECIAL WOODRUFF (25X18)
2	19511-Z1T-000	FAN, COOLING
2	19511-ZE1-000	FAN, COOLING
3	28451-Z1T-700	PULLEY, STARTER
3	28451-Z4M-003	PULLEY, STARTER
4	31110-Z1T-932	FLYWHEEL (MAHLE)
4	31110-Z4M-950	FLYWHEEL (YUXIN)
5	90201-878-003	NUT, SPECIAL (14MM)
5	90201-Z0T-800	NUT, SPECIAL (14MM)




FR. →
ZED0E1700

Ref #	Part #	Description
1	16854-ZH8-000	RUBBER, SUPPORTER (107MM)
2	16955-Z1T-010	JOINT, FUEL TANK
2	16955-ZE1-010	JOINT, FUEL TANK
4	17510-Z1T-930ZA	TANK, FUEL *NH31* (MCKINLEY WHITE)
4	17510-Z1T-930ZB	TANK, FUEL *NH1* (BLACK)
5	17620-Z4H-920*	CAP, FUEL FILLER
6	17631-Z0T-801	GASKET, FUEL FILLER CAP (39X62X3) (RADICON)
6	17631-Z1T-810	GASKET, FUEL FILLER CAP
7	17672-Z4H-000*	FILTER, FUEL
8	90004-ZH7-003	BOLT, FLANGE (6X29)
11	91353-671-003	O-RING (13.5X1.5) (ARAI)
12	91424-Z4M-023	TUBE, FUEL (4.5X145) (FKM)
13	94050-06000	NUT, FLANGE (6MM)
14	95002-40800-08	CLAMP, TUBE (D8)




ZED0E2000

Ref #	Part #	Description
1	30500-Z1T-601	COIL ASSY., IGNITION (TOYO)
1	30500-Z1T-701	COIL ASSY., IGNITION (KOKUSAN)
2	30700-Z1T-601	CAP ASSY., NOISE SUPPRESSOR (TOYO)
2	30700-Z1T-701	CAP ASSY., NOISE SUPPRESSOR (KOKUSAN)
3	32195-Z1T-701	WIRE, STOP SWITCH (370MM) (KOKUSAN)
3	36101-ZE1-010	WIRE, STOP SWITCH (370MM)
4	90121-952-000	BOLT, FLANGE (6X25) (CT200)




ZED0E2000

Ref #	Part #	Description
1	87516-Z4N-010	MARK, OPERATOR CAUTION (ENGLISH)
2	87521-Z4M-000	EMBLEM (GX160)
3	87528-Z4M-000	MARK, CHOKE
4	87532-ZH7-000	MARK, THROTTLE INDICATION
5	87539-Z4M-000	MARK, EX. CAUTION (ENGLISH)




Ref #	Part #	Description
1	18310-Z4M-811	MUFFLER (ARRESTER)
3	18320-Z4M-000	PROTECTOR, MUFFLER (STD)
4	18355-ZE1-000	ARRESTER, SPARK
6	18381-Z0T-801	GASKET, MUFFLER
6	18381-Z1T-003	GASKET, MUFFLER (GUANGZHOU LEAKLESS)
6	18381-Z1T-701	GASKET, MUFFLER (NINGBO SIL GASKET)
9	90050-ZE1-000	SCREW, TAPPING (5X8)
10	90055-ZE1-000	SCREW, TAPPING (4X6)
11	94001-08000-0S	NUT, HEX. (8MM)



ZED0E4000


Ref #	Part #	Description
4	87516-Z4N-801	MARK, OPERATOR CAUTION (FRENCH)
5	87519-Z4N-000	MARK, OPERATOR CAUTION (PICTOGRAPH)
7	87539-Z4M-800	MARK, EX. CAUTION (PICTOGRAPH)
8	87539-Z4M-810	MARK, EX. CAUTION (FRENCH)



FR. →


ZED0E0800

Ref #	Part #	Description
1	13010-Z1T-931	RING SET, PISTON (STD) (TPR)
1	13010-Z1T-932	RING SET, PISTON (STD) (RIKEN) (NA USE ALT:13010-Z1T-931)
2	13101-Z1T-930	PISTON (STD)
3	13111-Z1T-000	PIN, PISTON
3	13111-Z4M-000	PIN, PISTON
3	13111-ZDK-003	PIN, PISTON
4	13200-Z1T-930	ROD ASSY., CONNECTING
5	90001-Z4M-000	BOLT, CONNECTING ROD (6X34.5)
6	90551-ZE1-000	CLIP, PISTON PIN (18MM)



ZED0E1100

Ref #	Part #	Description
1	28400-ZED-801ZA*	STARTER ASSY., RECOIL *R280* (POWER RED)
1	28400-ZED-801ZB	STARTER ASSY., RECOIL *NH1* (BLACK)
2	28410-ZED-801ZA	CASE, RECOIL STARTER *R280* (POWER RED)
2	28410-ZED-801ZB	CASE, RECOIL STARTER *NH1* (BLACK)
3	28421-Z1T-702	REEL, RECOIL STARTER (BLACK)
4	28422-Z1T-701	RATCHET, STARTER
5	28431-ZH8-801	PLATE, FRICTION
6	28433-Z1T-702	GUIDE, RATCHET
7	28441-ZH8-801	SPRING, FRICTION
8	28442-ZH8-003	SPRING, RECOIL STARTER
9	28443-Z1T-701	SPRING, RETURN
10	28461-ZED-801	KNOB, RECOIL STARTER
11	28462-ZH8-003	ROPE, RECOIL STARTER
12	28463-ZED-801	KNOB, REINFORCEMENT
13	90003-ZH8-801	SCREW, SETTING
14	90008-ZE2-003	BOLT, FLANGE (6X10)
14	95701-06008-08	BOLT, FLANGE (6X8)



ZED0E2900

Ref #	Part #	Description
2	89218-ZE1-000	WRENCH, SPARK PLUG